# INSTALLATION INSTRUCTIONS

## FLEXVIEW FVS SERIES SOUNDBAR MOUNT

## THANK YOU

Thank you for purchasing the FlexView Soundbar Mount. Please read these instructions thoroughly before installing this product. Refer to I-00668 or I-00069 FlexView FVS Series Instruction Sheet for additional information.

#### Horizontal Soundbar 10-32 x 1/2" Studs (4) **TOOLS REQUIRED Bracket** • 3/8 Nut Driver M4 Nut Driver Phillips Screwdriver Vertical Monitor Flange Mounting Nuts (4) -HARDWARE KIT INCLUDES Brackets 10-32 (2)**DESCRIPTION** QTY 20 10-32 Flange Nuts 10-32 x 1/2" Studs 4 12 Washers 6 M4 x 12MM Phillips Head Screws 6 M4 Flange Nuts Flange FIGURE A Nuts (4) 10-32 **INSTALLATION** 1) Determine VESA spacing and mount (2) vertical soundbar brackets to horizontal soundbar bracket at desired height using (4) 10-32 flange Vertical Soundbar Brackets (2) nuts and (4) studs. (FIGURE A)

WEIGHT RATING: 20 lbs. Maximum

Flange Nut 10-32 (6 per

soundbar bracket)

(Refer to soundbar mounting instructions if Soundbar necessary). (FIGURE B) Mounting Horizontal Brackets (2) Soundbar NOTE: (6) M4 screws, (12) washers and (6) flange Bracket nuts are provided for installation (suitable for most applications). 3) Secure mounted soundbar assembly to horizontal soundbar bracket using (12) 10-32 flange nuts. (FIGURE B) 4) Secure vertical soundbar brackets with attached soundbar to vertical monitor mount brackets FIGURE B using (4) 10-32 flange nuts. (FIGURE A)

M4 Flange Nut/Washer/Stud

2) Attach soundbar mounting brackets to soundbar

Soundbar

Middle Atlantic Products

Rev -

I-00671



#### **WARRANTY**

Middle Atlantic Products (the "Company") warrants the FlexView FVS Series Soundbar Mount to be free from defects in material or workmanship for the lifetime of the product.

The Company's entire liability to the purchaser, and the purchaser's (or any other party's) sole and exclusive remedy, under this warranty shall be limited, at the Company's option, to either (a) return of and refund of the price paid for, or (b) repair or replacement at the Company's factory of the products purchased, or any part or parts thereof, which the Company has determined to be defective after inspection thereof at the Company's factory.

This warranty does not cover damage due to acts of God, accident, misuse, abuse or negligence by parties other than the Company, or any modification or alteration of the products. In addition, this warranty does not cover damage due to improper handling, assembly, installation or maintenance.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL THE COMPANY BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT, OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION OR ANY OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OF THE PRODUCTS PURCHASED, EVEN IF THE COMPANY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE COMPANY'S LIABILITY TO THE PURCHASER (OR ANY OTHER PARTY) HEREUNDER, IF ANY, SHALL IN NO EVENT EXCEED THE PURCHASE PRICE OF THE PRODUCTS PAID TO THE COMPANY.

### **Corporate Headquarters**

Corporate Voice 973-839-1011 - Fax 973-839-1976 / International Voice +1 973-839-8821 - Fax +1 973-839-4982 middleatlantic.com - info@middleatlantic.com

## Middle Atlantic Canada

Voice 613-836-2501 - Fax 613-836-2690 / middleatlantic.ca - customerservicecanada@middleatlantic.ca

## **Factory Distribution**

USA: NJ - CA - IL Canada: ON - BC

At Middle Atlantic Products we are always listening. Your comments are welcome.

Middle Atlantic Products is an ISO 9001 and ISO 14001 Registered Company.