

Dispensing Tool Assembly Instructions

1. To assemble the dispensing tool, insert the piston. While lifting the metal tab, slide piston with ratchet teeth side down, into the slot through the front end. Push the piston all the way through and gently release the metal tab. The metal tab should catch on the ratchet teeth.
2. Insert BonDuit® Conduit Adhesive cartridge into the wide opening on the retaining collar. Push the collar back and press firmly to snap into place.
3. Twist cap 90° to remove from cartridge. Place mixing nozzle onto cartridge and lock into place by twisting. Save cap for storage of unused material.



Lift Metal Tab



Insert Piston



Open Tool



Insert Cartridge