Cable Entrance Plates and Hood



Reversible • Non-metallic • Cable protection at its best





Install one of Arlington's low voltage mounting brackets (not supplied) at entry and/or exit locations. Use LV1 for the single-gang CE1,



1 For entry location: Use the mounting bracket as a template, and cut hole for entry location. Feed wires into the cable entrance

plate. Make sure that the hood is in the desired orientation; facing in or out.

2 For wire exit: Install low voltage mounting bracket (repeat above instructions). Fish wires from behind the wall surface and pull through the bracket. Feed wires into CE1 or CE2 with the hood in the correct orientation (in or out).



- 3 Attach both (entry and/or exit) cable entrance plates to the LV1 or LV2 mounting brackets.
- 4 Connect wires to electronic equipment.



CE2 w/ plate facing IN

Catalog Number	UPC/DEI/NAED Mfg. #018997	Description Non-metallicCableEntrancePlate	Plate Color	Unit/Std Pkg	Includes screws that match plate color
CE1	10460	Single gang	White	10	
CE2	10461	Two gang	White	10	

Arlington's new REVER SIBLE entrance plate not only protects cable, but delivers good looks and installation versatility.

Use it facing IN – or OUT. It's easy to install. And, it's the best way to run cable where you want it.

- Non-rusting, paintable plastic
- Versatile, easy to use
- · Install facing in or out



See reverse for Cable Entrance Hood for decorator plates

The SCOOP [™] Cable Entrance Hood for Decorator Plates

Reversible • Non-metallic • Installation versatility

For good looks and installation versatility with decorator-style wall plates, try Arlington's reversible non-metallic, single gang entrance hood.


- Easy to install, facing IN or OUT
- Protects low voltage cable against damage.


It's the best way to run cable where you need it.



Patent pending











Installation Instructions

Use one or more of Arlington's low voltage mounting brackets (not supplied) to install The SCOOP™ – the single-gang LV1, two-gang LV2, three-gang LV3 or four-gang LV4.

- 1 Use the mounting bracket as a template, then cut hole for entry location. Attach the mounting bracket to the wall.
- 2 Feed wires through The SCOOP™ (CED1), with it facing in or out, as desired. Attach to the mounting bracket with the supplied screws. Repeat as many times as necessary.
- 3 Connect wires to electronic equipment.

Catalog Number	UPC/DEI/NAED Mfg. #018997	Description Non-metallicCableEntranceHood	Plate Color	Unit/Std Pkg	Includes two#6 screws
CED1	10465	Single gang	White	10	